

Control Panel Configurations



Small Monochrome Screen & Soft Keys
Models: Mint 110



Medium Screen & Soft Keys
Models: Mint 210 Series



Large Color Touchscreen & Soft Keys
Models: Mint 310 Series




Each Model has a set of shortcut keys to eliminate extra keystrokes for efficient mail processing

Control Panel Layout & Functions

Control Panel Layout

- 1) Screen (may be display-only or touch-enabled, depending on model)
- 2) Menu system navigation buttons (touchscreens require fewer)
- 3) Shortcut keys
- 4) Alphanumeric keypad
- 5) Start/Stop buttons



Control Panel Functions

Display, select or access:

- Postal class, rates & services
- Weighing modes
- Print options
- Accounts (spending allocation)
- Job presets
- Funds management
- System settings

Noteworthy features

- Fast and easy menu navigation that makes learning curves short
- **Shortcut keys** take users directly to the most commonly-used menu functions
- **Imprint memories** allow users to save settings (such as the postage value, print selections and account) as a one-touch preset for frequent jobs
- The most popular mail classes can be selected in 1 or 2 seconds using **rate shortcuts**